

VERY IMPORTANT
INSTRUCTION SHEET FOR EASY RUNNER ASSEMBLY

FAILURE TO FOLLOW THESE INSTRUCTIONS COULD RESULT IN INJURY AND MUST BE COMPLETED PRIOR TO SITTING IN ROCKER.

CAUTION: STANDING IN THE ROCKER OR ATTEMPTING TO TIP ROCKER OVER BY "OVER-ROCKING" MAY RESULT IN SERIOUS INJURY.

TOOL REQUIRED: HAMMER

1. DISTINGUISH THE FRONT OF THE RUNNERS.
2. PLACE ROCKER IN INVERTED POSITION AND TAP RUNNERS ON FRONT LEG FIRST. DO NOT PUT RUNNER COMPLETELY ON FRONT UNTIL RUNNER HAS BEEN STARTED ON BACK.
3. KNOCK RUNNERS ON BACK LEG. FORCE MAY BE REQUIRED TO GET RUNNER ON. IF RUNNER DOES NOT SEEM TO FIT, KNOCK BACK LEG FORWARD AND TRY AGAIN.
4. AFTER RUNNERS ARE FITTED ON ALL LEGS, NAIL (PROVIDED) RUNNERS INTO ALL LEGS FROM THE INSIDE.

TOUCH UP:

TO HELP YOU IN TOUCHING UP YOUR ROCKERS THE FOLLOWING KRYLON COLORS ARE AVAILABLE AT YOUR LOCAL HARDWARE OR HOME CENTER.
WHITE: 1502, HUNTER GREEN 2001, BLACK 1631,
NATURAL 1301

